

Kovanie na WC kabíny

UPEVNENIE TRUBKY CS-F30



99-13700030

**TRUBKA PREPOJOVACIA 32MM
CS - S32 NEREZ 6M**



99-13700032

**ZÁMOK S INDIKÁTOROM OBSADENÉ-
VOLNÉ 1370CO - L5500 NEREZ**



99-13705500

**SPOJ TRUBKY ROHOVÝ CS - 80
NEREZ 90ST**



99-13700080

**SPOJKA TRUBKY VT - T70
NEREZ**



99-13700270

**ZÁVES NA KABÍNKY CT - H70L
NEREZ**



Lavý: 99-13700070

Pravý: 99-13700170

**NOHA REKTIFIKAČNÁ VS - U0000
UNIVERZÁLNA NEREZ**



99-13701000

**ÚCHYTKA DO DVERÍ H380
NEREZ**



99-13703800

**UHOLNÍK KABÍNKY PRICHYTENIE
K STENE VS - BL450 NEREZ**



99-13700450

**DORAZ NA DVERE CS - S49
NEREZ**



99-13700049

**SKRUTKY/ZÁMOK
1371CO-L55/18,M4/30**



99-13715518

**SKRUTKY ZÁVES NA KABÍNKY
CT - H70 / 18**



99-13717018

Obrázky sú ilustračné.